


2. DO NOT TOUCH INTERNAL ELECTRONICS OR INSTRUMENTATION THIS COULD DAMAGE THE TRANSDUCER AND WILL VOID THE WARRANTY.

3. Tool Side RING-PLUG Option Moves Origin. See 9230-05-1059 for Position.

4. DO NOT EXCEED INTERFACE DEPTH, MAY CAUSE DAMAGE 5. Transducer must be mounted to surfaces rigid enough to support loads without deflection for best accuracy.



ASSEMBLY REF:



ISO 9001 Registered Company

PROPERTY OF ATI INDUSTRIAL AUTOMATION, INC. NOT TO BE REPRODUCED IN ANY MANNER EXCEPT ON ORDER OR WITH PRIOR WRITTEN AUTHORIZATION OF ATI.

REVISION

07

DRAWN BY: B. Digeso 3/3/00 CHECKED BY: D. Norton 7/15/05 SCALE WEIGHT LBS:

Gamma Transducer without Mounting Adapter

DRAWING NUMBER 1:1 9230-05-1103

Description

Initiator

SHEET 1 OF 1 PRODUCT RELEASE # -